

KROMEK STEPS UP TO THE PLATE WITH ITS HANDHELD DETECTORS

Kromek supports the EMPIR Preparedness Project with 10 Handheld Detectors.

Summary

To enhance radiation detection across Europe, 10 of our networkable D3S ID detectors and a D3M were deployed as part of the EMPIR Preparedness Project, and their detection range and accuracy tested extensively by the UK's National Metrological Institute. Kromek's detectors were deemed optimal for rapid detection during emergencies and for long-term radiation monitoring of the environment and public spaces.

Challenge

Ionising Radiation can cause sickness or even death in those exposed to it. Nuclear incidents can arise by accident or, potentially, by direct acts of terrorism. In both scenarios an accurate knowledge of the amount and type of radiation present is important to allow appropriate decisions and introduce countermeasures.

Static radiation monitors offer excellent coverage for areas of national security such as airports, railways and ship terminals but can be bypassed and are not easily relocated. To detect neutrons, released by materials such as plutonium, many of these also require Helium-3 (He-3) which has a limited global supply. Immobile detectors may also fail, as in the case of Fukushima in 2011, leading to a lack of knowledge about the types and levels of radiation present.



Multiple, mobile detectors capable of collectively pooling data could support information gained from static detectors and significantly extend real-time coverage of radioactive threats or the illicit trafficking of radioactive materials.

However, existing portable radiation monitors in Europe were 'stand-alone' with limited coverage. Environmental radioactive sources could also cause interference, generating false alarms. Little was also known on the effect on measurement accuracy and reproducibility of combining measurements from multiple detectors, essential to ensure an appropriate response to a nuclear incident.

KROMEK STEPS UP TO THE PLATE WITH ITS HANDHELD DETECTORS



Solution

In the [EMPIR Preparedness Project](#), ten [Networkable D3S](#) and [D3M Handheld Gamma and Neutron Radiation Detectors](#) were supplied by project partner Kromek, a leading developer of Radiation Detection Products and Solutions. Field trials were then performed to examine range and accuracy under high and low radiation dose fields.

At NPL, the UK's National Metrological Institute (NMI) detectors were exposed to sources with varying radionuclides and their respective activities including Am-241, Cs-137 and Co-60. Results indicated these performed well, remaining responsive up to extreme dose rates at 1 Sv/hr with an accuracy of 50 micro Sv/hr.

To validate response to ultra-low radiation levels the units were examined in a reference field laboratory by PTB, Germany's NMI, before testing in the naturally low radiation levels of the Underground Laboratory for Dosimetry and Spectrometry (UDO) in the salt mine of esco (K+S) in Grasleben, Germany. This showed the detectors had an extremely low background reading of around 1.5 nSv/h and additional tests were performed at the UDO with radioactive sources Co-57, Co-60, Cs-137, Am-241 and Ra-226 with dose rates <300nSv/hr.

Impact

In 2014 America's Defense Agency DARPA initiated [SIGMA](#) an inter-linked network of portable radiation detectors and by 2019 this system was deployed to Europe. Through the work of the Preparedness project, Kromek was able to demonstrate the operability and high accuracy of its handheld devices and now offers its cost-effective, SIGMA compatible [D3S NET Gamma and Neutron Radiation monitor](#) for environmental monitoring.

Along with access to the SIGMA network it consists of a D3S Detector and an android app capable of identifying 42 isotopes – more than specified by the European standard IEC 62327 applying to handheld instruments used for detecting radioactive material.



KROMEK STEPS UP TO THE PLATE WITH ITS HANDHELD DETECTORS

The D3S NET can be deployed from vehicles, carried by personnel or mounted on drones for areas where radiation would be too harmful for humans. Not requiring exotic He-3, thousands can be linked via a telecommunication network, sending data to a central control point in seconds.

The detector can also discriminate between naturally occurring radiation, radiation from medical and industrial applications and special nuclear materials, such as plutonium and uranium, thus allowing a more informed response to an alert. The implementation of these types of sensor networks will provide greater safety to the public in the event of a nuclear incident and help prevent future terrorist threats.

Protecting the public from radiation exposure

The Preparedness project extended metrology for mobile detection of ionising radiation. Two new dose rate detectors were validated and three transportable systems for the monitoring of Gamma Ray emitting Radioactivity in the air were developed, calibrated and tested with industrial partners.

The ability of unmanned aerial drones to accurately detect natural and artificial radiation levels was investigated. Two intercomparison exercises were carried out at drone centres resulting in a good practice guide. New unmanned aerial detection systems were designed and prepared for production, realising novel concepts in ground radioactivity monitoring for nuclear or radiological emergency response.

The reliability of sixty-four passive dosimetry detectors systems used by 38 European dosimetry services was investigated for their capability to long-term monitoring of contaminated environmental areas. In addition, the largest ever analysis on monitoring radioactivity and ionizing radiation by non-governmental networks was performed, potentially complimenting results from Governmental detection networks.

The results of the project will support timely, effective action that protects the public and environment against the effects of ionising radiation in the aftermath of nuclear and radiological emergencies.



[Click here to see the Case Study on Euromet's Website](#)